




Gebrauchsanweisungen:

51 3564
(D,I,S,N,SF)

51 3565
(NL,F,E,GB)

Programmtabellen:

51 3552

(D)

51 3553

(I,S,N,SF)

51 3554

(S,DK)

51 3555

(NL,F,E,GB)

Aufstellanweisungen:

51 3556

(D,I,S,N,SF)

51 3557

(S,DK)

51 3558

(NL,F,E,GB)

1) 27 3989

(D)

28 3384

(Symbol)

Blende kompl.

2) 08 8915

(D,I)

08 8916

(NL,F)

08 8917

(E,GB)

08 8918

(SF,N)

3) 08 8912

15 5272

Triac-Motorleistung

