







Gebrauchsanweisung
51 3591
(D,GB,F,I,NL,S,SF,E,P,
DK,N)





TECHNISCHE DATEN / TECHNICAL DATA / DONNEES TECHNIQUES				
Verdichter/Compressor/Compresseur		Danfoss		
Typ/Type		TLES 7 K		
Förderleistung/Delivery/Débit	l/h	1168		
Anlaufstrom/Starting current/Cour de démarrage	A	4,5		
Widerstand/Resistance/Résistance	Ha/main/prin.	16,5		
	Hi/aux	16,9		
Temp.-Regler/Thermostat		Ranco		
Typ/Type		K 59		
Reglerstellung/Position		kalt	warm	
Schaltwerte/Switching values/	„ein“	+5,2	+5,2	
Valeurs de commutation	„aus“	-31,0	-13,5	
	(„abtauen“ od.)	„alarm“		
Füllmenge/Fill.quantity/Charge	R600a	g	*	*
Anschlußwert/Conn.load/Puiss. connectée	W			
Heizung/Heater/Chauffage				
Widerstand/Resistance/Résistance	Ω			
Leistung/Power/Puissance	W			
Ventilator/Blower/Ventilateur				
Widerstand/Resistance/Résistance	Ω			
Schaltuhr/Timer/Minuterie de contact				
Widerstand/Resistance/Résistance	Ω			
Magnetventil/Magnetic valve/Electrovanne				
Widerstand/Resistance/Résistance	Ω			
Spannung/Voltage/Tension	V			

* siehe Typenschild

	V01	V02	
Pos.	Danfoss	Danfoss	
	TLES 7 K	TLY 6 K	
1	14 1239	14 1680	
2			
3	15 1055	15 1055	
4			
5	15 0760	15 0760	
6	15 1072	15 1072	
7			
8	27 0291	27 0291	
9	05 0166	05 0166	
10			
11	08 4744	08 4744	
12	05 6008	05 6008	