





Gebrauchsanweisung
52 2261
(de,en,fr,it,nl,sv,fi,no,
da,es,pt)

- 1) 16 5709
- 2) 16 9749
- 3) 16 9753
- 4) 16 5727
- 5) 16 5720
- 6) 17 2274
- 7) 06 0115
- 8) 35 2777



TECHNISCHE DATEN/TECHNICAL DATA/DONNEES TECHNIQUES/DATOS TECNICOS				
Verdichter/Compressor/Compresseur/Compresor		DANFOSS		
Typ/Type/Tipo		TLES9KK2		
Förderleistung/Delivery/Debit/Aspiración l/h		1589		
Anlaufstrom/Starting current/Cour.démarrage/Int.arranque A		4.5		
Widerstand/Resistance/Resistencia. Ha/main/prin. Ohm		16.5		
Hi/aux.		19.9		
Temp.Reyler/Thermostat/Termostato		DANFOSS		
Typ/Type/Tipo		077B2507		
Reglerstellung/Position/Conexión		Kalt Warm.		
Schaltwerte/Switching values/		..ein"	C	-25 -17
Valeurs de commutation/Desconex.		..aus".		-33 -23
(..abtaven' od)		..alarm"		-19.5 -13
Füllmenge/Fill. quantily/Charge/Carga R600a		g	40	
Anschlusswert/Comm. load/Puiss. Connect./Potenc.		W	90	

1) 06 0182