





Gebrauchsanweisung
52 0956
(D,GB,F,NL,I,E,GR)
Montageanleitung
51 7955
(D,GB,F,NL,I,E,GR)
Tips und Rezepte
51 8100
(D)

Zubehör:


Grillpfanne u. Bratrost
Z1230X0
Backblech, Alu
Z1330X0
Backblech Email
Z1340X0
Bratrost gekröpft
Z1430X0

Bratrost engmaschig
Z1440X0
Backblech emailliert
Z1510X0
Nachrüstset
Z1730X0
Adapter MEGA
Z9600X0
Reinigerschwamm
15 5067


1) 02 5876
2) 03 0150
3) 03 0152



- 1) 15 5012
- 2) 15 5013
- 3) 15 5291
- 4) 15 5248
grün
- 5) 15 5247
rot
- 6) 15 9899
- 7) 15 9917
- 8) 15 9915



- 1) 15 4762
- 2) 15 4763
- 3) 02 6593
- 4) 16 2555



- 2) 09 6825
kompl.
- 3) 06 9709
- 4) 15 4836
- 5) 15 5033