

51 3649
Gebrauchsanweisung
 51 2001
 Tips und Rezepte

03 1612
Befestigungssatz

Zubehör:

Grillpfanne
 Z1220X0

Alu-Backblech
 Z1320X0


**Back- und
 Bratrost**
 Z1420X0

Teleskopschiene
 Z1721X0

Bratenblech
 Z1510X0


Drehspieß-Set
 Z1162X0


Brotbackstein
 Z1910X0




- 1) Düsensätze f.
 Stadtgas:
 02 1936
 Erdgas:
 02 1937
 Flüssiggas:
 05 2418
- 2) 02 6579
- 3) 05 2783
- 4) 05 4675
- 5) 05 4678

1) 05 4816





- 1) 02 7736
- 2) 02 7715
- 3) 02 7737
- 4) 02 5054
- 5) 02 7846



1) 02 6859

