


This diagram illustrates the exploded view of a refrigerator assembly, showing the main body, door, and various internal components. The parts are labeled with identification numbers and codes:

- Top and Door Components:** 13 0605, 04 5723, 07 3099, 07 1055, 07 2176, 12 3704, 19 1593, 04 4462 RE, 04 4470 LI, 19 2550, 10 5450, 10 2680, 19 2555, 19 2553.
- Internal Structure and Shelves:** 19 2552, 07 2874, 19 1824, 04 6237, 04 6236, 19 1784, 19 2551, 10 5472, 19 1829, 01 4139, 01 2994, 04 5729, 19 2554, 19 8216.
- Door and Hinge Assembly:** 13 0563, 07 2867, 07 2869, 01 4138 LI, 01 4137 RE, 04 5724, 10 4749, 04 5725, 04 5726, 04 5727, 04 5728, 07 2875, 07 2876, 01 3971, 01 4577, 01 3972, 10 4748, 19 2585, 19 1829, 10 4189, 19 1825.
- Base and Support Components:** 10 4439, 10 4748, 19 2553.

130603-2/1



SELBSTREINIGENDER HERD
EH 64 UR 2 - 0 750 292 005