




Gebrauchsanweisung
52 7156
(en)
Kochbuch
52 6877
(en)

1) 02 5876

Zubehör:

Backblech, Alu
Z1330X0


Backblech Email
Z1340X0


Brotbackstein
Z1910X0

Nachrüstsatz Clou4/Kat.
Z1750X0


Auflaufform
Z1270X0

Grillset klein
Z1240X0





- 1) 15 4762
- 2) 15 4763
- 3) 16 6510
- V01
- 16 6507
- V02, V03



- 1) 09 6825
kompl.
- 2) 15 4836
- 3) 16 0916