


**BOSCH**

FIX-QUIRL FQ 130

- 0 717 024 011-D1

- 0 717 024 012-D2

- 0 717 024 013-CH

KLEINE HAUSGERÄTE
QuirleIdent - Nummern - Konstante
3740

Gemüseschneider 0 717 099 004

Wendhalter
12 1452/05
Becher
12 0415/12
Passierstab
10 8836/071) 01 6189/02/23
2) 04 6720/01
3) 07 4250/24
07 4066/23
D2
4) 01 7470/03/5