





Gebrauchsanweisung
52 9358
(de,en,fr,nl,it,es,el)
Montageanleitung
51 7991
(de,en,fr,nl,it,es,el)

Kochbuch
52 1984
(de)


1) 02 5876

Zubehör:


Bratrost engmaschig
Z1440X0
Bratrost gekröpft
Z1430X0
Bratenblech
Z1510X1
Brotbackstein
Z1910X0
Grillpfanne u. Bratrost
Z1230X0
Nachrüstsatz Clou/Kat.
Z1740X0
Nachrüstsatz Clou4/Kat.
Z1750X0
Auflaufform
Z1270X0
Backblech Alu
Z1330X0
Backblech email.
Z1340X0



1) 18 3758



- 1) 02 6593
- 2) 17 2643
- 3) 29 9750
- 4) 17 2645
- 5) 17 2646
- 6) 17 2765



- 1) 15 5033
- 2) 26 1674
kompl.
- 3) 16 0916
- 4) 15 4836