




Gebrauchsanweisung
51 9317
(D)

Montageanleitung
51 7955
(D,GB,F,NL,I,E,GR)

Tips und Rezepte
51 8100
(D)

Zubehör:

Grillpfanne u. Bratrost
Z1230X0


Backblech, Alu
Z1330X0

Backblech Email
Z1340X0

Bratrost gekröpft
Z1430X0


Bratrost engmaschig
Z1440X0

1)02 5876



1) 16 2319
V01
16 2321
V02

- 1) 15 4762
- 2) 15 4763
- 3) 15 4764
- 4) 02 6593



1) 16 0916