





Gebrauchsanweisung  
52 8435  
(de)

1) 02 5876


Zubehör:

Back- u. Bratrost-  
engmasching  
Z1440X0  
Back- u. Bratrost  
gekröpft  
Z1430X0  
Backblech Alu  
Z1330X0  
Backblech Email  
Z1340X0  
Universalpfanne u.  
Bratrost  
Z1230X0



- 1) 18 2669  
V01  
18 2678  
V02  
18 2682  
V03
- 2) 18 2668  
V01  
18 2677  
V02  
18 2681  
V03





- 1) 18 2794  
V01  
18 3052  
V02  
18 2783  
V03
- 2) 17 2646
- 3) 18 2612  
V01  
18 2427  
V02, V03
- 4) 36 1788  
V01  
36 1920  
V02  
36 1923  
V03

- |         |     |
|---------|-----|
| 36 1789 | V01 |
| 36 1921 | V02 |
| 36 1924 | V03 |

