




Gebrauchsanweisung

58 1434 (de)
58 1435 (en)
56 1436 (nl)
58 1437 (fr)
58 1438 (el)

Zubehör:


Universalpfanne
HZ 23300


Kombirost
HZ23400


Backblech Alu
HZ 21000


Glasbräter
HZ 9150
Grillblech
HZ22500
Backblech emailliert
HZ23100

1) 01 4254









- 1) 29 7213
Set
- 2) 16 3067
Set

