




Ident - Nummern - Konstante
3740

Gebrauchsanweisung

52 2749-(DE)

52 2750-(GB)

52 2751-(FR)

52 2752-(NL)

52 2753-(DK)

52 2754-(IT)

52 2755-(ES)

52 2756-(PT)

52 2757-(GR)

52 2758-(SE)

52 2759-(NO)

52 2760-(FI)

Montageanleitung

51 6443

(D,F,GB,NL,I,DK,E,P
N,FIN,S,GR)

51 6464

Kochbuch (D)

Bratautomatikkarte

51 8365

(DE,GB,FR,IT,NL,ES)

Einbausatz

06 8506

Zubehör:

HZ 23000

Backblech Alu

HZ 23100

Backblech emailliert

HZ 22500

Grillblech

HZ 23300

Universalpfanne

HZ 23400

Kombirost

HZ 9150


Glasbräter


HZ 25070

CD-ROM-Rezepte


HZ 25001

Adapterkabel





- 1) 06 8581
2) 51 9252
Typenschild



Ident – Nummern – Konstante
3740

