




Gebrauchsanweisung
51 5565
A1, CH1, A2
(D, GB, F, I, NL, DK, N, S, SF, E,
P, GR)


1) 03 2798

Zubehör:


Heizkörperbürste
VZ 0683
schwarz

Möbelpinsel
VX 0773
schwarz

Turbobürste
VZ470900
schwarz



46 0077
schwarz
kompl.




02 7109




08 0857

02 9169

45 0759
schwarz
kompl.




28 7684




45 0140

46 0097
schwarz



46 0098
schwarz



46 0123
schwarz

