





Gebrauchsanweisung
58 2593 (en)

Montageanweisung
52 4904
(de,en,fr,it,nl,da,sv,no
fi,es,pt,el,cs,pl,tr,ru)

Zubehoer:
HZ21004
Backblech Alu
HZ21100
Backblech emailliert
HZ21300
Universalpfanne
HZ21400
Kombirost
HZ22400
Einlegerost
HZ21710
Teleskopauszug
HZ21700
Profi-Auszug
HZ24701
Deckel f. Profipfanne
HZ22500
Grillblech
HZ9150
Glasbraeter
HZ26000
Metallbraeter

1) 01 4254





Zubehoer
HZ26001
Backform
Auslaufsicher
HZ25300
Aktiv-Kat.
HZ21610
Katalyse-Set

1) 48 1284
Set

