



Gebrauchsanweisung
52 3269
(DE,TR,GB,RU)

1) 16 5552








35 4159




26 2266



16 3401



- 1) 35 4164
- 2) 35 4166
- 3) 17 1321
- 4) 48 0520
V01
48 0648
V02
- 5) 48 0519
V01
48 0646
V02



Pos.	V01		
	Danfoss		
	NLY13K		
1	14 2045		
2	16 5570		
3	35 4158		
4	16 3427		
5	26 5327		
6	17 1318		
7	17 1519		
8	18 1014		
9			
10			
11			
12			

TECHNISCHE DATEN/TECHNICAL DATA/TEKNIK BİLGİLER			
Verdichter/Compressor/Kompresör		Danfoss	
Typ/Type/Tip		NLY13K	
Förderleistung/Delivery/Verim/h			
Anlaufstrom/Starting current/Giris akimi	A	6.6/10.9	
Widerstand/Resistance/Rezistans Ha/Hi/aux.	Ohm	10.7	
		13	
Temp.Reyler/Thermostat/Termostat		K59/P1777	
Typ/Type/Tip			
Reglerstellung/Position/Termostat pozisyonu			
Schaltwerte/Actua kapama degerleri	..ein/acma °C	+3.5 +3.5	
Valeurs de commutation/Termostat degeri	..aus"/kapama	-31 -20	
(..abtaven' od)	..alarm'		
Füllmenge/Fill. quantily/ Dolum miktari	R600 g	*	
Anschlusswert/Comm. load/Giris gucu	W	*	
Heizung/Heater/Rezistans			
Widerstand/Resistance/Direnc	Ohm		
Leistung/Power/Guc	W		
Ventilador/Blower/Vantilatör			
Widerstand/Resistance/Rezistans	Ohm		
Magnetventil/Magnetic valve/Manyetik valf			
Widerstand/Resistance/Rezistans	Ohm		
Spannung/Voltage/Gerilim	V		
Temp.Reyler/Thermostat/Termostat			

* Siehe Typenschild/Mamul etiketine bakiniz