




Mat. - Nr. - Konstante
3740

Gebrauchsanweisung
51 6969
(D, F, GB, I, NL, E)

Montageanleitung
51 6089
(D, GB, F, I, NL)

Programmtabelle
51 7579
(D, GB, F, I, NL, E)

Kochbuch
51 5732
(D)
V01, V03
51 5859
(NL)
V02, V04
51 6251
(GB)
V05

Zubehör:


Alu-Backblech
HMZ19BB


Glaspfanne
HMZ10GP

Glasbräter
HMZ21GP

Mat. – Nr. – Konstante
3740

- 1) 03 0671
Stössel
2) 03 0813
Arretierstift






Mat. - Nr. - Konstante
3740

- 1) 11 4538 Backblech
- 2) 11 4539 Rost
- 3) 11 4537 Glasschale
- 4) 27 0323 V01,V02,V03,V04
27 1620 V05

02 8732
Anschlag für Backblech



Mat. – Nr. – Konstante
3740

1) 06 6760

