




Gebrauchsan- und
Montageanweisung
51 9366
(D)

Tips und Rezepte
51 8100
(D)

Zubehör:

Grillpfanne u. Bratrost
Z1230X0


Backblech, Alu
Z1330X0

Backblech Email
Z1340X0


Bratrost gekröpft
Z1430X0

Bratrost engmaschig
Z1440X0


1)02 5876



1) 16 6289
2) 16 6288



- 1) 15 4762
- 2) 15 4763
- 3) 15 4764
- 4) 02 6593



1) 16 0916