





Gebrauchsanweisung
52 8451
(de)

1) 02 5876

Zubehör:


Back- u. Bratrost-
engmasching
Z1440X0
Back- u. Bratrost
geköpft
Z1430X0
Backblech Alu
Z1330X0
Backblech Email
Z1340X0
Universalpfanne u.
Bratrost
Z1230X0




1) 18 2645
V01
18 2656
V02

36 1925
V01
36 1927
V02

18 3053
V01
18 3054
V02



- 1) 15 4762
- 2) 15 4763
- 3) 16 7255
- V01
- 16 7262
- V02



1) 15 4779