






Gebrauchsanweisung
58 4616
(de)

Zubehör:


Back- u. Bratrost-
engmasching
Z1440X0
Back- u. Bratrost
geköpft
Z1430X0
Backblech Alu
Z1330X0
Backblech Email
Z1340X2
Universalpfanne u.
Bratrost
Z1230X2



1) 18 2645
V01
18 2656
V02



- 1) 15 4762
- 2) 15 4763
- 3) 16 7255
- V01
- 16 7262
- V02



1) 15 4779