

- 2) 48 0159 (fr)
 48 0193 (de)
 36 0026 (en)
 48 0194 (it)
 36 0027 (ru)
 36 0028 (es)
 36 0030 (el)
 48 0541 (pl)
 48 1989 (cs)

Gebrauchsanweisung

- 58 4391 (de)
 58 4393 (fr)
 58 4394 (nl)
 58 4395 (it)
 58 4396 (en)
 58 4397 (ru)
 58 4406 (es)
 58 4407 (el)
 58 4408 (pl)
 58 3420 (cs)


Aufstallanweisung

- 58 4401 (ru)
 58 4339 (de)
 58 4384 (fr)
 58 4400 (en)
 58 4399 (it)
 58 4398 (nl)
 58 4410 (el)
 58 4409 (es)
 58 4412 (pl)
 58 4411 (cs)

Programmtabelle


- 52 6675 (fr)
 52 6933 (de)
 52 7191 (nl)
 52 7300 (en)
 52 7301 (ru)
 52 7229 (it)
 52 7455 (es)
 52 7456 (el)
 52 7681 (pl)
 58 3421 (cs)

- 1) Blende kompl.
 36 0087 (nl) V01
 36 0294 (de) V02
 35 9989 (nl) V03



1) 2 x pro Gerät

Zubehör:
 Bodenbefestigung
 WX9756
 Entkalker
 46 0038



- 1) 26 3372
- 2) 26 3373
- 3) 16 5983
- 4) 26 3395
- 5) 16 5984
- 6) 48 0138
- kompl.
- 8) 16 5978

