




Gebrauchsanweisung

52 2432 (sv)
52 2433 (fi)
52 2434 (no)
52 2435 (da)

Aufstellanweisung

52 0634 (fi)
52 0635 (no)
52 0636 (sv)
52 0637 (da)

Programmtabelle


52 2436 (sv)
52 2438 (fi)
52 2439 (no)
52 2440 (da)

1) Blende kompl.
36 0272 (fi)


Zubehör:

Bodenbefestigung
WX9756

Entkalker
46 0038



1) 2 x pro Gerät



- 1) 26 3372
- 2) 26 3373
- 3) 16 5983
- 4) 26 3395
- 5) 16 5984
- 6) 48 0138
- 8) 16 5978
- 9) 16 7191
- 10) 16 7192

16 2546
Kabelbaum
NTC Fühler

