





Gebrauchsanweisung
52 3151
(D,F,NL,I)


Montageanleitung
52 3152
(D,F,NL,I)

1) 02 5876


Zubehör:

Back- u. Bratrost-
engmasching
Z1440X0
Back- u. Bratrost
geköpft
Z1430X0
Backblech Alu
Z1330X0
Backblech Email
Z1340X0
Universalpfanne u.
Bratrost
Z1230X0





- 1) 15 4762
- 2) 15 4763
- 3) 16 7255
- V01,V02
- 16 7262
- V03,V04



1) 15 4779