





Gebrauchsanweisung
58 7250
(de)

Kochbuch
58 4760
(de)


Zubehör:

Dampfgarer
N8640X2


Bratrost engmaschig
Z1440X0
Bratrost gekröpft
Z1430X0
Backblech, Alu
Z1330X0
Backblech Email
Z1340X2
Bratenblech
Z1510X2
Brotbackstein
Z1910X0
Grillpfanne u. Bratrost
Z1230X2
Auflaufform
Z1270X2



1) 41 9022
2) 18 1066



- 1) 15 4762
- 2) 15 4763
- 3) 17 1615



- 1) 26 1674
kompl.
2) 41 8562